



















# Quick Parameter Reference V3.8X

## CFW500 Frequency Inverter




Document: 10007479673/04

**NOTE!**

For further information, please, refer to the programming manual available for download at [www.weg.net](http://www.weg.net).

**1 USE OF THE HMI TO OPERATE THE INVERTER**



- When in the setting mode, **level 1**: press this key to return to the monitoring mode.
- When in the setting mode, **level 2**: press this key to return to **level 1** of the setting mode.
- When in the setting mode, **level 3**: press the key to cancel the new value (new value is not saved) and return to **level 2** of the setting mode.



- When in the monitoring mode: press this key to increase the speed.
- When in the setting mode, **level 1**: press this key to go to the previous group.
- When in the setting mode, **level 2**: press this key to go to the next parameter.
- When in the setting mode, **level 3**: press this key to increase the content of the parameter.

- Press this key to define the motor rotation direction.  
Active when:  
P0223 = 2 or 3 in LOC and/or P0226 = 2 or 3 in REM.
- Press this key to commute between LOCAL and REMOTE mode.  
Active when:  
P0220 = 2 or 3.

- Press this key to accelerate the motor up to the speed set in P0122 within the time determined by the acceleration ramp. The motor speed is kept while the key is pressed. When the key is released, the motor decelerates within the time determined by the deceleration ramp, until it stops. This function is active when all the conditions below are met:
  1. Turn/Stop = Stop.
  2. Enable general = Active.
  3. P0225 = 1 in LOC and/or P0228 = 1 in REM.

**1.1 INDICATIONS ON THE HMI DISPLAY****1.2 OPERATING MODES OF THE HMI****2 MAIN PAREMETERS****NOTE!**

ro = read only parameter.  
V/f = parameter available in V/f mode.  
cfg = configuration parameter, value can only be changed with the motor stopped.  
VVW = parameter available in VVW mode.  
VVW PM = parameter available in VVW PM mode.  
Vector = parameter available in vector mode.  
Sless = parameter available only in sensorless mode.  
Enc = parameter available only in vector mode with encoder.

Param.	Description	Adjustable Range	Factory Setting	Propr.	Groups
P0000	Access to Parameters	0 to 9999	0	ro	READ
P0001	Speed Reference	0 to 65535		ro	READ
P0002	Output Speed (Motor)	0 to 65535		ro	READ
P0003	Motor Current	0.0 to 200.0 A		ro	READ
P0004	DC Link Voltage (Ud)	0 to 2000 V		ro	READ
P0005	Output Frequency (Motor)	0.0 to 500.0 Hz		ro	READ
P0006	Inverter Status	0 = Ready 1 = Run 2 = Undervoltage 3 = Fault 4 = Self-Tuning 5 = Configuration	6 = DC-Braking 7 = STO 8 = Fire Mode 9 = Reserved 10 = Sleep Mode		READ
P0007	Output Voltage	0 to 2000 V		ro	READ
P0010	Output Power	0.0 to 6553.5 kW		ro	READ
P0011	Power Factor	-1.00 to 1.00		ro	READ
P0012	D18 to D11 Status	Bit 0 = D11 Bit 1 = D12 Bit 2 = D13 Bit 3 = D14 Bit 4 = D15 Bit 5 = D16 Bit 6 = D17 Bit 7 = D18		ro, READ, I/O	
P0013	D05 to D01 Status	Bit 0 = D01 Bit 1 = D02 Bit 2 = D03	Bit 3 = D04 Bit 4 = D05	ro	READ, I/O
P0022	FI Hz Value	0 to 20000 Hz		ro	READ, I/O
P0023	Main SW Version	0.00 to 655.35		ro	READ
P0030	Heatsink Temperature	-20 to 150 °C		ro	READ
P0037	Motor Overload Int	0 to 100 %		ro	READ
P0047	CONF Status	0 to 999		ro	READ
P0048	Present Alarm	0 to 999		ro	READ
P0049	Present Fault	0 to 999		ro	READ
P0050	Last Fault	0 to 999		ro	READ
P0100	Acceleration Time	0.1 to 999.0 s	10.0 s	BASIC	
P0101	Deceleration Time	0.1 to 999.0 s	10.0 s	BASIC	
P0120	Speed Ref. Backup	0 = Inactive 1 = Active 2 = Backup por P0121	1		
P0121	Keypad Reference	0.0 to 500.0 Hz	3.0 Hz	BASIC	
P0133	Minimum Speed	0.0 to 500.0 Hz	3.0 Hz	BASIC	
P0134	Maximum Speed	0.0 to 500.0 Hz	66.0 (55.0) Hz	BASIC	
P0135	Max. Output Current	0.0 to 400.0 A	1.5 x I <sub>nom</sub>	V/I, VVV, VVW, PM	BASIC, MOTOR
P0136	Manual Torque Boost	0.0 to 30.0 %	According to inverter model	V/I, VVV, PM	BASIC, MOTOR
P0156	Overload Current 100 %	0.0 to 400.0 A	1.1 x I <sub>nom</sub>		
P0157	Overload Current 50 %	0.0 to 400.0 A	1.0 x I <sub>nom</sub>		
P0158	Overload Current 5 %	0.0 to 400.0 A	0.8 x I <sub>nom</sub>		
P0202	Type of Control	0 = V/A 1 and 2 = Not Used 3 = Sensorless 4 = Encoder	5 = VVW 6 and 7 = Not Used 8 = VVW PM	0	cfg, STARTUP
P0204	Load/Save Parameters	0 and 1 = Not Used 2 = Reset P0045 3 = Reset P0043 4 = Reset P0044 5 = Load WE6 60 Hz 6 = Load WE6 50 Hz 7 = Load User 1 8 = Load User 2 9 = Save User 1 10 = Save User 2 11 = Load Default SoftPLC 12 to 15 = Reserved	7 = Load User 1 8 = Load User 2 9 = Save User 1 10 = Save User 2 11 = Load Default SoftPLC 12 to 15 = Reserved	0	cfg
P0220	LOC/REM Selection Src	0 = Always Local 1 = Always Remote 2 = HMI Key (LOC) 3 = HMI Key (REM) 4 = Dlx 5 = Serial/USB (LOC)	6 = Serial/USB (REM) 7 and 8 = Not Used 9 = CO/DN/PB/Eth (LOC) 10 = CO/DN/PB/Eth (REM) 11 = SoftPLC	2	cfg, I/O
P0221	LOC Reference Sel.	0 = HMI Keys 1 = A11 2 = A12 3 = A13 4 = Fl 5 = A11 + A12 > 0 6 = A11 + A12 7 = E/P 8 = Multispeed	9 = Serial/USB 10 = Not Used 11 = CO/DN/PB/Eth 12 = SoftPLC 13 = Not Used 14 = A11 > 0 15 = A12 > 0 16 = A13 > 0 17 = Fl > 0	0	cfg, I/O
P0222	REM Reference Sel.	See options in P0221	6 = Serial/USB (A-H) 7 and 8 = Not Used 9 = CO/DN/PB/Eth (H) 10 = CO/DN/PB/Eth (AH) 11 = Not Used 12 = SoftPLC	1	cfg, I/O
P0223	LOC FWD/REV Selection	0 = Clockwise 1 = Counter-clockwise 2 = HMI Key (H) 3 = HMI Keys (AH) 4 = Dlx 5 = Serial/USB	6 = Serial/USB (A-H) 7 and 8 = Not Used 9 = CO/DN/PB/Eth (H) 10 = CO/DN/PB/Eth (AH) 11 = Not Used 12 = SoftPLC	2	cfg, I/O
P0224	LOC Run/Stop Selection	0 = HMI Keys 1 = Dlx 2 = Serial/USB	3 = Not Used 4 = CO/DN/PB/Eth 5 = SoftPLC	0	cfg, I/O
P0225	LOC JOG Selection	0 = Disable 1 = HMI Keys 2 = Dlx 3 = Serial/USB	4 = Not Used 5 = CO/DN/PB/Eth 6 = SoftPLC	1	cfg, I/O
P0226	REM Rotation Selection	See options in P0223	4 = Not Used 5 = CO/DN/PB/Eth 6 = SoftPLC	4	cfg, I/O
P0227	REM Run/Stop Selection	0 = Telia HMI 1 = Dlx 2 = Serial/USB	3 = Not Used 4 = CO/DN/PB/Eth 5 = SoftPLC	1	cfg, I/O
P0228	REM JOG Selection	See options in P0225	5 = SoftPLC	2	cfg, I/O

**4 DEFAULT CONFIGURATION FOR SPEED REFERENCE AND COMMAND**

The CFW500 is configured at the factory by setting its parameters so as to define the logical command and the speed reference in both LOCAL and REMOTE operating modes. This default setting can be restored by means of P0204 for both motors 60Hz and 50Hz (P0204 = 5 or 6).

In the LOCAL mode, the command and reference are directed to the HMI of the CFW500, allowing the commands Run/Stop, JOG and Direction of Rotation of the motor. In addition to these commands, the HMI keypad can also be used to select the LOCAL or REMOTE mode. The speed reference can be set in P0121 or by means of the and keys of the HMI in the monitoring mode.

In the REMOTE mode, the speed reference and command are directed to the product terminals; DI1 executes Run/Stop and DI2 the Direction of Rotation. The reference is executed by analog input AI1 in this mode.

**3 FAULTS AND ALARMS**

Most common faults and alarms

Fault/Alarm	Description	Possible Causes
A0046	Motor Overload	■ Settings of P0156, P0157, and P0158 are too low for the used motor ■ Overload on the motor shaft
A0050	Power Module Overtemperature	■ High ambient temperature around the inverter (> 50 °C (> 122 °F)) and high output current ■ Blocked or defective fan ■ Heatsink is too dirty, preventing the air flow
A0990	External Alarm via D1x (option "No External Alarm" in P026x)	■ Wiring on DI1 to DI8 inputs are open or have poor contact
A0700	Communication Fault with Remote HMI	■ Check if the communication interface with the HMI is properly configured in parameter P0312 ■ HMI cable disconnected
F0021	Undervoltage on the DC Link	■ Wrong voltage supply check if the data on the inverter label comply with the power supply and parameter P0296 ■ Supply voltage is too low, producing voltage on the DC link below the minimum value (in P004): Ud < 200 Vdc in 200-240 Vac (P0296 = 0) Ud < 360 Vdc in 380-480 Vac (P0296 = 1) Ud < 500 Vdc in 500-600 Vac (P0296 = 2) ■ Phase fault in the input ■ Fault in the pre-charge circuit
F0022	Overvoltage on the DC Link	■ Wrong voltage supply; check if the data on the inverter label comply with the power supply and parameter P0296 ■ Supply voltage is too high, producing voltage on the DC link above the maximum value (in P004): Ud > 410 Vdc in 200-240 Vac (P0296 = 0) Ud > 810 Vdc in 380-480 Vac (P0296 = 1) Ud > 1000 Vdc in 500-600 Vac (P0296 = 2) ■ Load inertia is too high or deceleration ramp is too fast ■ P0151, P0153 or P0185 setting is too high
F0031	Communication Fault with Plug-In Module	■ Plug-In module is damaged ■ Plug-In module is not properly connected ■ Problem in the identification of the Plug-In module; refer to P0027 for further information
F0051	IGBTs Overtemperature	■ High ambient temperature around the inverter (>50 °C (>122 °F)) and high output current ■ Blocked or defective fan ■ Heatsink is too dirty, preventing the air flow
F0070	Overcurrent/Short-Circuit	■ Short circuit between two motor phases ■ Short circuit of the rheostatic braking resistor connecting cables ■ IGBTs module in short- circuit or damaged ■ Start with too short acceleration ramp ■ Start with motor spinning without the flying-start function
F0072	Motor Overload	■ P0156, P0157 and P0158 setting is too low in relation to the motor operating current ■ Overload on the motor shaft
F0080	CPU Fault (Watchdog)	■ Electric noise ■ Inverter firmware fault
F0084	Auto-Diagnosis Fault	■ Poor contact in the connection between the main control and the power pack ■ Hardware not compatible with the firmware version ■ Defect on the internal circuits of the inverter
F0091	External Fault	■ External fault via D1x ("No External Fault" in P026x)
F0700	No communication with remote HMI, but there is speed command or reference for this source	■ Check if the communication interface with the HMI is properly configured in parameter P0312 ■ HMI cable disconnected









# 快速参考引用 V3.8X

## CFW500 变频器

### 1 使用HMI操作变频器



#### 1.1 HMI显示屏指示



#### 1.2 HMI操作模式



### 2 主要参数



**注意!**  
 ro = 只读参数。  
 V/f = V/f 模式下的可用参数。  
 cfg = 配置参数，数值只能在电机停止后更改。  
 VW = VW 模式中的可用参数。  
 矢量 = 矢量模式中的可用参数。  
 Slens = 仅是无传感器模式中的可用参数。  
 Enc = 含编码器矢量模式中的可用参数。

文件: 100749673/04  
17153459

参数	描述	可调节范围	出厂设置	归属主体	组别	
P0000	参数入口	0 至 9999	0			
P0001	速度参考值	速度参考值 0 至 65535	ro	读取		
P0002	输出速度(电机)	0 至 65535	ro	读取		
P0003	电机电流	0.0 至 200.0 A	ro	读取		
P0004	直流感节电压(Ud)	0 至 2000 V	ro	读取		
P0005	输出频率(电机)	0.0 至 500.0 Hz	ro	读取		
P0006	变频器状态	0 = 故障 1 = 运行 2 = 低压 3 = 故障 4 = 自动调谐 5 = 配置	ro	读取		
P0007	输出电压	0 至 2000 V	ro	读取		
P0010	输出功率	0.0 至 6553.5 kW	ro	读取		
P0011	功率系数	-1.00 至 1.00	ro	读取		
P0012	D18 至 D1 状态	0 位 = D11 1 位 = D12 2 位 = D13 3 位 = D14 4 位 = D15 5 位 = D16 6 位 = D17 7 位 = D18	ro	读取, 输入/输出		
P0013	D05 至 D01 状态	0 位 = D01 1 位 = D02 2 位 = D03 3 位 = D04 4 位 = D05	ro	读取, 输入/输出		
P0014	FI Hz 值	0 至 20000 Hz	ro	读取, 输入/输出		
P0023	主要 SW 版本	0.00 至 655.35	ro	读取		
P0030	散热器温度	-20 至 150°C	ro	读取		
P0037	电机过载 Ixt	0 至 100 %	ro	读取		
P0047	配置状态	0 至 999	ro	读取		
P0048	当前警报	0 至 999	ro	读取		
P0049	当前故障	0 至 999	ro	读取		
P0050	上次故障	0 至 999	ro	读取		
P0100	加速时间	0.1 至 999.0 秒	10.0 s	基础		
P0101	减速时间	0.1 至 999.0 秒	10.0 s	基础		
P0120	速度参考备份	0 = 无效 1 = 有效 2 = 经 P0121 备份	1			
P0121	键盘参考	0.0 至 500.0 Hz	3.0 Hz			
P0133	最低速度	0.0 至 500.0 Hz	3.0 Hz	基础		
P0134	最高速度	0.0 至 500.0 Hz	66.0 (55.0) Hz	基础		
P0135	最大输出电流	0.0 至 400.0 A	1.5 x I <sub>nom</sub> V/f, VW, VVW PM	基础, 电机		
P0136	手动转矩提升	0.0 至 30.0 %	根据变频器型号 V/f, PM	基础, 电机		
P0156	过载电流100%	0.0 至 400.0 A	1.1 x I <sub>nom</sub>			
P0157	过载电流50 %	0.0 至 400.0 A	1.0 x I <sub>nom</sub>			
P0158	过载电流 5 %	0.0 至 400.0 A	0.8 x I <sub>nom</sub>			
P0202	控制类型	0 = V/f 1 = V/VW 2 = 未使用 3 = 无传感器 4 = 编码器	0	cfg	启动	
P0204	负载/保存参数	0 和 1 = 未使用 2 = 重置 P0045 3 = 重置 P0043 4 = 重置 P0044 5 = 负载 WEG 60 Hz 6 = 负载 WEG 50 Hz 7 = 加载用户 1 8 = 加载用户 2 9 = 保存用户 1 10 = 保存用户 2 11 = 加载默认 SoftPLC 12 至 15 = 保留	0	cfg		
P0220	LOC/REM 选择 Src	0 = 始终本地 1 = 总是远程 2 = HMI 键 (本地) 3 = HMI 键 (远程) 4 = DIx 5 =串口/USB端口 (LOC) 11 = SoftPLC	2	cfg	输入/输出	
P0221	LOC参考选择	LOC参考选择 0 = HMI 键 1 = AI1 2 = AI2 3 = AI3 4 = FI 5 = AI1 + AI2 > 0 6 = AI1 + AI2 7 = E.P. 8 = 多速	9 = 串口/USB 10 = 未使用 11 = CO/DN/PB/Eth (LOC) 10 = CO/DN/PB/Eth (REM) 11 = SoftPLC	0	cfg	输入/输出
P0222	REM参考选择	见P0221中的选项	1	cfg	输入/输出	
P0223	LOC FWD/REV 选择	0 = 顺时针 1 = 逆时针 2 = HMI 键 (H) 3 = HMI 键 (AH) 4 = DIx 5 =串口/USB (H)	6 = 串口/USB (AH) 7和8 = 未使用 9 = CO/DN/PB/Eth (H) 10 = CO/DN/PB/Eth (AH) 11 = 未使用 12 = SoftPLC	2	cfg	输入/输出
P0224	LOC 运行/停止 选择	0 = HMI 键 1 = DIx 2 = 串口/USB	3 = 未使用 4 = CO/DN/PB/Eth 5 = SoftPLC	0	cfg	输入/输出
P0225	LOC JOG 选择	0 = 禁用 1 = HMI 键 2 = DIx 3 = 串口/USB	4 = 未使用 5 = CO/DN/PB/Eth 6 = SoftPLC	1	cfg	输入/输出
P0226	REM 旋转选择	见P0223中的选项	4	cfg	输入/输出	
P0227	REM 运行/停止 选择	0 = Tecla HMI 1 = DIx 2 = 串口/USB	3 = 未使用 4 = CO/DN/PB/Eth 5 = SoftPLC	1	cfg	输入/输出
P0228	REM JOG 选择	见P0223中的选项	2	cfg	输入/输出	

### 3 故障和警报

#### 最常见故障和警报

故障/警报	描述	可能原因
A0046	电机过载警报	■ P0156, P0157和P0158的设置值对于所用电机过低 ■ 电机轴过载
A0050	功率模块过热	■ 变频器周围高温 (0 ~ 50 °C (122 °F)) 及高额输出电流 ■ 风扇堵塞或故障 ■ 散热器过热, 导致空气无法流通
A0090	通过DIx (P026x中的“外部警报”选项) 发出外部警报	■ DI1 至 DI8 输入接线断开或接触不良
A0700	外部警报	■ 检查 HMI 通信接口是否按参数 P0312 正确配置 ■ HMI 电缆断开
F0021	中间电路超压故障	■ 供电不符: 检查变频器标签上的数是否符合电源及参数 P0296 ■ 电源电压过低, 导致 DC Link 上的电压低于最小值 (P0004 中): UD < 200 Vdc 在 200~240 Vac (P0296 = 0) UD < 360 Vdc 在 380~480 Vac (P0296 = 1) UD < 500 Vdc 在 500~600 Vac (P0296 = 2) ■ 输入端子短路 ■ 预充电电容故障
F0022	中间电路过电压	■ 供电不符: 检查变频器标签上的数是否符合电源及参数 P0296 ■ 供给电压太高时, 在 (P0004) 高于最大值的直流感节上产生过电压: UD > 410 Vdc 在 200~240 Vac (P0296 = 0) UD > 810 Vdc 在 380~480 Vac (P0296 = 1) UD > 1000 Vdc 在 500~600 Vac (P0296 = 2) ■ 负载设置过高或减速斜坡太快 ■ P0151, P0153或P0155设置过高
F0031	主控制板不能设置插入模块的通信连接	■ 插入模块损坏 ■ 插入模块不能正确连接 ■ 识别插入模块问题: 参考P0027获取更多信息
F0051	IGBTs 过热	■ 变频器周围高温 (0 ~ 50 °C (122 °F)) 及高额输出电流 ■ 风扇堵塞或故障 ■ 散热器过热, 导致空气无法流通
F0070	输出/直流感节或制动电阻器电流过大或短路	■ 两个电机相间短路 ■ 制动电阻器连接电线短路 ■ IGBT 模块短路或损坏 ■ 启动加速斜坡过短 ■ 未使用快速启动功能启动电机旋转
F0072	电机过载故障 (在 1.5xInom 内 60 s)	■ 与电机操作相关的 P0156, P0157 和 P0158 的设置值过低 ■ 电机轴过载
F0080	与变频器主 CPU 的监管算法相关的故障	■ 电子噪音 ■ 变频器固体故障
F0084	变频器硬件和插入模块自动识别算法相关的故障	■ 主要控制器件与电源组接触不良 ■ 硬件不兼容/固件版本 ■ 变频器内部电路故障
F0091	通过DIx (P026x中的“外部故障”选项) 发出外部故障	■ DI1 至 DI8 输入接线断开或接触不良
F0700	外部故障	■ 检查 HMI 通信接口是否按参数 P0312 正确配置 ■ HMI 电缆断开

### 4 速度参考和指令默认配置

CFW500出厂时已设置好参数,以便在本地和远程操作模式中定义逻辑指令和速度参考值。通过60Hz和50Hz电机的P0204存储该默认设置 (P0204=5或6)。

在本地模式中,指令和参考指向CFW500的HMI,允许指令运行/停止、JOG和电机旋转方向。除了这些指令, HMI键盘还可以用于选择本地或远程模式。可在P0121或通过在监控模式下的HMI **▲** 和 **▼** 两个键设置速度参考值。

在远程模式中,速度参考值和指令指向产品终端; D11执行运行/停止, D12执行旋转方向。参考值由该模

块中的模拟输入AI1执行。